

Men's Shirt – Measure your best fitting shirt

Please note that the shirt should be laid flat on a table or smooth surface for proper measurement



1. COLLAR

The collar measurement should be taken from the middle of the button hole to the center of the collar button when the collar is spread flat.

HALF CHEST



2. HALF CHEST

Button the shirt and lay it flat. Then measure from left seam to right seam just below the armpit.




3. HALF WAIST

With the shirt laid flat, measure from left seam to right seam at the waistline




4. HALF HIPS

With the shirt laid flat, measure from left seam to right seam at the base of the shirt.



5. SLEEVE LENGTH
 Lay a sleeve flat and measure along the outside edge (opposite to the sleeve seam) from the top of the shoulder (starting at the seam) to the end of the cuff.



5.1 ELBOW
 When you require a width for the elbow, provide us with the “Elbow reference point” and “Elbow width”.
Elbow reference point: Measure from top shoulder seam (point **A**) as seen on image above to where your elbow normally sits when you wear a shirt (point **D**).
Elbow width: Measure from points **D** to **Y** as shown in the image above.
5.2 FOREARM
 When you require width for the forearm, provide us with the “Forearm reference point” and “Forearm width”.
Forearm reference point: Measure from top shoulder seam (point **A**) as seen on image above to where your forearm normally sits when you wear a shirt (point **C**).
Forearm width: Measure from points **C** to **X** as shown in the image above.



6. HALF BICEP

With the shirt laid flat, measure the width of your sleeve at the upper arm.

****Half armhole is always bigger than half bicep.**

Normally, half armhole is at least 6cm bigger than half bicep.**



7. CUFF

Spread the cuff on flat surface. Place the measuring tape on the center of the buttonhole and measure across to center of the button.



8. YOKE

Measure the distance between the sleeves, from one edge of the shoulder to the other, across the back.



9. SHOULDER

Measure the distance between sleeve and collar along the shoulder seam. ***This is a secondary reference. **Yoke** is primarily considered when submitting measurements from well fitting shirt.***



10. SHIRT LENGTH

Measure at the back from the base of the collar seam at the middle to a point where the shirt ends.



11. HALF ARMHOLE

Place the shirt on a large flat surface so the front of the shirt is facing you. Place the measuring tape at the top of the armhole seam and follow it along its edge to the point where the armhole meets the sleeve seam. (Note: this is a curved measurement, so please measure carefully.)

****Half armhole is always bigger than half bicep.
Normally, half armhole is at least 6cm bigger than half bicep.****

--	--